

# "IMC" Edition Boot Dr.™ Guards ♦ Installation Instructions:

- 1: Using the supplied allen wrench, screw-in the two, self-locking set screws into the two clamp blocks until you can see them coming out & into the seating channel approx 1/8".

You **DO NOT** need to add Loctite® to the set screws as they already come with a SELF-LOCKING NYLON insert.



The set screws should screw in fairly easily (some resistance is normal) - if they don't, back them out a half-turn, then screw back in, to avoid stripping the heads.

**NOTE:** We also suggest using a small bead of *Clear Silicon* in the seating channel between the lock blocks to reduce the possibility of the **BOOT DR™** loosening over time due to engine vibration.  
→This step is recommended, but **NOT mandatory**.

- 2: Slip the **BOOT DR™** on from the TOP of the footboard (slip it in on in the space between the footboard & the pipe). Make sure it is seated properly, with a uniform guard height above the footboard, and then tighten the 2 set screws underneath until **SNUG!!**

**CAUTION:** Use **ONLY** the supplied allen wrench for install, **DO NOT USE** any other extension which can **over-torque** the clamp & possibly distort or damage the **BOOT DR™**

**\*\* BE CAREFUL NOT TO OVER-TIGHTEN THE SET SCREWS!! \*\***

- 3: **YOU ARE DONE!! ....So Get out on the road and RIDE!!!**

## NOTE:

If you **DO NOT** have enough clearance between the floorboard & the pipe to slip on the **BOOT DR™**, you will need to **REMOVE** the floorboard to complete the install.

*(This is TYPICAL when running THUNDER HEADER Pipes)*

- 1: Remove the floorboard from your bike by loosening the two bolts that attach it to its mounting bracket. (2 bolts shown in photo below)



- 2: While holding the **BOOT DR™** in place, tighten down the two self-locking allen head set screws located inside each clamp block by using the supplied allen.



- 3: Re-attach the floorboard to the bracket and re-tighten the two bolts.



- 4: **YOU ARE DONE!!**



**INDIAN MOTORCYCLE CERTIFIED QUALITY**

**Warranty:** This product has been officially licensed by Indian® Motorcycle Company. Under the terms of the licensing agreement, MD, Inc. (Manufacturer) agrees to provide the following warranty: MD, Inc. warrants that this product, if properly installed, maintained and operated under normal conditions, shall be free from any defects in materials and workmanship for a period of **90 days** from original date of purchase. All products have been manufactured with the highest standards of quality control & materials. MD, Inc. will **REPLACE** any defective product **FREE OF CHARGE**, upon receipt of the original/defective product, for the purpose of inspection & quality control. **ALL shipping charges** incurred in the return of the product shall remain the sole responsibility of PURCHASER. To **initiate a warranty claim**, please call our Toll Free number **(888)266-8362**. You will need to provide us with the following information: Date and Proof of Purchase, Name & Address of Dealer where you purchased the product, and Purchase Price.  
**NOTE:** MD, Inc. maintains the right to **REFUSE** any warranty claims due to improper use or improper installation.

**Thank You for your purchase & RIDE SAFE!**