

Installing Your Chrome Choke Knob
(for Mikuni carb.) part # 88-130

Tools Required:

Common Channel Lock
1/16" Allen Wrench

Remove old choke knob by grasping at base of choke knob with the bottom jaw of your channel locks. Place the upper jaw on the brass point (this is the cable end) in the middle of the stock plastic knob. Squeeze on the channel locks, this will press the choke cable end out of the plastic knob. Place new choke knob onto cable and push until firmly in place. Using 1/16" allen wrench, tighten set screw in choke knob. Check for proper operation of choke.