

SN-5

PERIMETER SENSOR INSTALLATION MANUAL AND USER'S GUIDE


Mounting the SN-5

The Perimeter sensor uses high frequency microwave technology to detect mass density movement around the motorcycle. The signal can transmit through the seat, fiberglass, leather and plastic, but not metal. It is recommended to place this sensor under the seat as close as possible to the center of the motorcycle. With the provided Velcro, you can mount this sensor on top of the battery or any flat surface, making sure that the top side of the sensor is facing upwards.

Adjusting the SN-5

Although the sensor is pre set from the factory it may be necessary to adjust the sensitivity to suit your specific application.

1. Stand at least 10' away from the motorcycle and arm the system.
2. Walk towards the motorcycle and try and lean over the top of it. Once the sensor detects movement the siren will begin to chirp slowly. If you back away from the motorcycle the siren will stop chirping. If you continue to move closer to the motorcycle the siren will start to chirp faster and faster and then go into a full alarm.
3. Sensitivity can be adjusted by removing the rubber cap and tuning the adjustment screw. To increase sensitivity, turn adjustment screw clockwise. To decrease sensitivity, turn the adjustment screw counter clockwise. **PLEASE NOTE: DO NOT TURN SENSITIVITY ABOVE HALF WAY. THIS MAY CAUSE FALSE ALARMS.**
4. The Perimeter sensor has an internal tuning control, which has been set at the factory. This tuning control should only be changed if the sensor can not be properly set as described in #3 above. Please call Aritronix' technical support at (480)951-1109, before attempting to adjust it.



Aritronix
14435 N. Scottsdale Rd. Suite 500
Scottsdale AZ 85254
Technical Assistance (480) 951-1109